

# List of Warning/Indicator Lights






<sup>\*:</sup> It also comes on due to natural causes such as natural air leaks and tire inflation pressure changes caused by temperature. Adjust the tire inflation pressure to the specified level. The light will turn off after a few minutes. In case the light does not turn off even if the tire inflation pressure is adjusted, have the system checked by your Lexus dealer.

# If the electronic key does not operate properly


## ■Unlocking and locking the doors



Use the mechanical key in order to perform the following operations:


- 1 Locks all the doors
- Closes the windows and moon roof\* (turn and hold)
- 3 Unlocks all the doors Turning the key rearward unlocks the driver's door. Turning the key once again within 5 seconds unlocks the other doors.
- 4 Opens the windows and moon roof\* (turn and hold)
- \*: This setting must be customized at your Lexus dealer.

## ■Unlocking the trunk



Turn the mechanical key clockwise to open.

### ■ Starting the engine



- 1 Ensure that the shift lever is in P and depress the brake pedal.
- Touch the Lexus emblem side of the electronic key to the engine switch.

  The engine switch will turn to IGNI-TION ON mode.

  When the smart access system with push-button start is deactivated in customization setting, the engine switch
- Firmly depress the brake pedal and check that is shown on the multi-information display.

will turn to ACCESSORY mode.

4 Press the engine switch.

In the event that the engine still cannot be operated, contact your Lexus dealer.

If the electronic key battery becomes depleted, replace it with a new battery. For instructions on replacing the battery, refer to the Owner's Manual. If you need further assistance, contact your Lexus dealer.

## If the engine doesn't start

Make sure that the correct operating procedures have been followed.

Brake pedal

Make sure that the brake pedal is firmly depressed when attempting to start the engine.

If the engine still does not start, see the Owner's Manual for more information or contact your Lexus dealer.

